



# Toshiba Satellite c650d Battery Replacement

This guide will provide directions for removing and replacing the Toshiba Satellite C650D battery.

Written By: Brenna Callahan



## INTRODUCTION

If you are encountering problems with the battery, and need to replace or remove it, follow the instructions provided in this guide. Make sure to read the safety guide before attempting the steps outlined below.



### PARTS:

- [Toshiba Satellite C650D Replacement Battery](#) (1)
-

## Step 1 — Battery



- Unplug the laptop and turn it off.
- Flip the laptop upside down.
- Locate the battery on the underside of the laptop.

## Step 2



- Push the two latches away from the battery.

## Step 3



- Slide the battery away from the laptop.
- Locate the serial number on the battery to order a replacement.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 09:50:03 AM.